

Installation Information: Warmwater Underfloor Heating System

- DINGO 2-Layer Bamboo Flooring
- DINGO Industrial Flooring
- DINGO DURABAM

The warmwater underfloor heating system must be installed according to the instructions of the manufacturer.

Above listed DINGO Bamboo Flooring must be glued down to the concrete subfloor.

The glue applied must be - according to the manufacturer of the glue - suitable for warmwater underfloor heating systems.

Before the installation of the flooring on a new warmwater underfloor heating system it must have been in function for at least two weeks and it must have been turned on to its maximum power for at least two times.

About two days before the installation of the flooring the warmwater underfloor heating system has to be turned off and the concrete subfloor must have cooled down to 18-20°C.

After the installation of the flooring the warmwater underfloor heating system can be turned on again and be warmed up carefully within a period of time of about one week.

- The temperature on the surface of the concrete subfloor should not exceed 25°C.
- The air humidity of the room should be kept between 50 % and 65 %.